







Mounting instructions

ekey dLine fingerprint scanner (door handle)


ekey

YOUR FINGER. YOUR KEY.

ID356/828/0/836: Version 2, 2025-02-07



RECOMMENDED MOUNTING HEIGHT



⚠ ATTENTION

Property damage in the event of incorrect mounting and wiring: The system devices are operated using electricity. They could be destroyed if they are mounted and wired incorrectly. Mount and wire the system devices correctly before connecting the power.

📄 NOTICE

These Mounting instructions are not subject to updating. We reserve the right to make technical modifications and change the product's appearance; any liability for errors and misprints is excluded.